

Removing the keyguard.

WARNING! To avoid damage to the keyguard for this device, please follow these simple steps *in order*. Please review all steps prior to handling the keyguard.


1 Place THUMBS on top edge of the device, gently roll the clips off with your fingers




DO NOT put thumbs on face of keyguard and attempt to bend the corner



2 Release BOTH TOP CLIPS and slide keyguard down



DO NOT PRY keyguard off with corners attached



DO NOT PRY or 'yank' the keyguard free!

At any point in the above process, **DO NOT pry or 'yank'** the keyguard from the underside as this may cause damage. Make sure to remove the top two clips **first** to avoid damage.

If you have followed these removal steps, the keyguard should detach from device with ease, requiring little force.

Version 1.0 05 2022